









Why use **Enhanced Exit** Signage?

Exit signs aren't always seen

Exit signs, with the running man symbol, are effective in their purpose, however only around 38% of people actually notice Exit signs during evacuations.

This means many people will likely not know they are actually near a fire exit, and could take far longer to evacuate by either going out of the building the way they entered (which could be a substantial distance), or they may spend unnecessary time deciding which way to go to find an exit.



Doubles the awareness of exit signage

is **reduced** by 45%

Research has proven that over twice as many people (77%) will see Dynamic **GREEN Exit** signs...



The Enhanced EXIT signage 'Dynamic GREEN' by Clevertronics, applies a principle of activating bright, sequencing green LEDs to increase the visibility of Exit signs, activated during a power failure, or by a building's safety system or fire detection system.

Research has proven that over twice as many people (77%) will see Dynamic GREEN Exit signs, and therefore will be more likely to take the nearest exit during evacuations far more quickly than static Exit signs.

Dynamic GREEN Enhanced EXIT signs helps to keep building occupants safe.



clevertronics.co.nz

Clevertronics Enhanced Exit Signage

Enhances a building occupants' ability to exit a building quickly and safely.

Exit signage locations and design as per BCA and AS2293 requirements Dynamic mode activates upon a power failure (emergency mode) V No additional "system" or interfacing required (although an option if required)

Cleverfit Pro & Ultrablade Styles

- Anual test and Zoneworks XT HIVE compatible
- All directional and running man options available
- Weatherproof Enhanced Exit signage also available

Codemark certification provides BCA compliance for products and technologies that are not specifically covered by an existing Standard.









Auckland

Unit 22/761 Great South Road Penrose Auckland 1061 Phone: +64 800 548 448 Email: nzsales@clevertronics.co.nz

Christchurch

163C Wordsworth Street Sydenham Christchurch 8023 Phone: +64 800 548 448 Email: nzsales@clevertronics.co.nz

Victoria

1 Caribbean Drive Scoresby VIC 3179 Phone: +61 3 9559 2700 Fax: +61 3 9559 2799 Email: vicsales@clevertronics.com.au

New South Wales

9 Distribution Place Seven Hills NSW 2147 Phone: +61 2 8805 6400 Fax: +61 2 8805 6444 Email: nswsales@clevertronics.com.au

Queensland

2/8-12 Monte-Khoury Drive Loganholme QLD 4129 Phone: +61 7 3442 9700 Fax: +61 7 3442 9777 Fmail: gldsales@clevertronics.com.au

Western Australia

12 Milly Court Malaga WA 6090 Phone: +61 8 9207 0000 Fax: +61 8 9248 3725 Email: wasales@clevertronics.com.au

South Australia U2/19 Main Terrace Richmond SA 5033 Phone: +61 8 8301 8800 Fax: +61 8 8351 8286 Email: sasales@clevertronics.com.au

clevertronics.co.nz